




## DESIGN OF A HIGH ACTIVITY AND SELECTIVITY ALCOHOL CATALYST. SIXTH QUARTERLY REPORT, NOVEMBER 7, 1991--FEBRUARY 7, 1992

DELAWARE UNIV., NEWARK. CENTER FOR CATALYTIC SCIENCE AND TECHNOLOGY

07 FEB 1992



U.S. Department of Commerce National Technical Information Service

### **One Source. One Search. One Solution.**





### **Providing Permanent, Easy Access** to U.S. Government Information

National Technical Information Service is the nation's largest repository and disseminator of governmentinitiated scientific, technical, engineering, and related business information. The NTIS collection includes almost 3,000,000 information products in a variety of formats: electronic download, online access, CD-ROM, magnetic tape, diskette, multimedia, microfiche and paper.





### Search the NTIS Database from 1990 forward

NTIS has upgraded its bibliographic database system and has made all entries since 1990 searchable on **www.ntis.gov.** You now have access to information on more than 600,000 government research information products from this web site.

### Link to Full Text Documents at Government Web Sites

Because many Government agencies have their most recent reports available on their own web site, we have added links directly to these reports. When available, you will see a link on the right side of the bibliographic screen.

### **Download Publications (1997 - Present)**

NTIS can now provides the full text of reports as downloadable PDF files. This means that when an agency stops maintaining a report on the web, NTIS will offer a downloadable version. There is a nominal fee for each download for most publications.

For more information visit our website:

## www.ntis.gov



U.S. DEPARTMENT OF COMMERCE Technology Administration National Technical Information Service Springfield, VA 22161

Do*E*/PC40291-

DOE/PC/90291-~T7

5

DE93 008100

### DESIGN OF A HIGH ACTIVITY AND SELECTIVITY ALCOHOL CATALYST

### Sixth Quarterly Report for Period November 7, 1991 to February 7, 1992

### Henry C. Foley and G. Alex Mills Coprincipal Investigators

1

### Center for Catalytic Science and Technology Department of Chemical Engineering University of Delaware Newark, Delaware 19716

Date Published: February 7, 1992

Prepared for Fossil Energy Department of Energy

Under Award No. DE-FG22-90PC 90291

US/DOE Patent Clearance is not required prior to publication of this document.

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

:

÷

DISCLAIMER

Pursuant to our goal of developing a better understanding of the methanol dehydration chemistry present in our alcohol synthesis system, we have prepared, tested, and characterized three sets of modified alumina catalysts. Furthermore, as a base case, native  $\gamma$ -Al<sub>2</sub>O<sub>3</sub> was tested in our low-pressure microreactor system for methanol dehydration activity. Next, two series of K-doped  $\gamma$ -Al<sub>2</sub>O<sub>3</sub> were prepared. The first was prepared by slurrying samples of  $\gamma$ -Al<sub>2</sub>O<sub>3</sub> with excess KNO<sub>3</sub> ion-exchange solution of varying concentrations for 24 hr at room temperature, followed by 16 hr of calcination in air at 300 °C. The second series of K-doped aluminas was prepared by saturating the pore volume of the alumina to incipient wetness with KNO<sub>3</sub> solution. Again, these samples were calcined in air at 300 °C for 16 hr.

Finally, a series of K-doped 2.8% Rh-3.4% Mo/ $\gamma$ -Al<sub>2</sub>O<sub>3</sub> catalysts have been prepared. Here, our starting material was a bimetallic Rh-Mo catalyst that was synthesized by sequential chemisorption of Mo and Rh carbonyls using a method described in a previous report (Fourth Quarterly Report, for period ending August 7, 1991). Samples of this bimetallic catalyst were then contacted with varying concentrations of excess KNO<sub>3</sub> solution, stirred 24 hr at room temperature, and once again, calcined for 16 hr in air.

The ultimate K content of the materials prepared was determined by elemental analysis. Each series of samples was tested in our low-pressure microreactor for methanol dehydration activity and the results of the tests were compared to the activity of our base-case test of native  $\gamma$ -Al<sub>2</sub>O<sub>3</sub>. As a complement to the microreactor studies, additional characterization of the samples consisted of examining the infrared spectroscopic properties of adsorbed pyridine, as will be described below.

### **Low-Pressure Microreactor Studies**

Samples were analyzed in a low-pressure microreactor for methanol dehydration activity. The material being tested was loaded in a Pyrex reactor tube, placed on-line with feed gas and heated in a tube furnace to reaction temperature. Methanol was delivered to the fixed bed of catalyst by passing a He carrier gas through a methanol bubbler located upstream of the reactor. The saturated He/methanol vapor mixture was then fed to the reactor. Downstream effluent was analyzed by gas chromatography using a flame ionization detector. The reaction conditions listed below for native  $\gamma$ -Al<sub>2</sub>O<sub>3</sub> are representative of those employed while testing all the samples discussed herein.

2

2

Reactor Temperature:	180 °C
Catalyst Weight:	0.5 g
Mesh Size:	60 x 100 (~200 µm in diameter)
He Carrier Gas Feed Rate:	50 sccm
Bubbler Temperature:	10 °C

In addition to the conditions above, the transition-metal loaded samples were reduced prior to the introduction of the methanol feed for 4 hr in excess H<sub>2</sub> at 300 °C. The salient reactor components used in our low-pressure (approximately atmospheric) reactor are shown in Figure 1.

Figure 2 illustrates the influence of doping the  $\gamma$ -Al<sub>2</sub>O<sub>3</sub> surface with K by confirming that as the K loading increases on the surface of the samples, the conversion of methanol to dimethyl ether (DME) (the expected dehydration product) drops considerably. The second key feature of Figure 2 is the magnitude of potassium loading. The loading of K reflected in Figure 3, in contrast to the samples indicated in Figure 2, is considerably lower. Figure 3 depicts the conversion of methanol as a function of K-doping on the Rh-Mo bimetallic catalyst. With regard to the magnitude of K loading, when compared to native  $\gamma$ -Al<sub>2</sub>O<sub>3</sub>, significantly less potassium has been deposited on the surface of the bimetallic catalyst. Here, we would argue that this is evidence that the process of sequentially adsorbing the Mo and Rh on the alumina, has tirated much of the latent acidity of the alumina that would otherwise have been available for ion exchange with the K<sup>+</sup> cations. Also, while Figure 3 does not depict a convincing trend in the effect of K-doping on the bimetallic Rh-Mo catalyst, the magnitude of the conversion of methanol on these samples is nearly an order of magnitude greater than that on the bare alumina.

The apparent disparity in the level of the conversion of methanol on the Rh-Mo catalysts as compared to the native alumina can be resolved by recognizing the presence of an additional methanol decomposition pathway on the Rh-Mo catalysts. Namely, the methanol can interact with the active metal phase on these materials, perhaps by dissociatively adsorbing on the metals and subsequently breaking down into other  $C_1$  products as well as recombining into light alkanes and olefins. Figures 4 and 5 lend support to this hypothesis. Figure 4 depicts the yield of DME (as opposed to the conversion of methanol) from the same set of reactor test shown in Figure 3. When considered in combination, Figures 3 and 4 indicated that while 30 to 50% of the methanol fed to the reactor is reacted, only a small fraction is converted to methanol's expected dehydration product, DME. Additional gas chromatographic evidence for the

3

formation of light hydrocarbons from the methanol was evident in that the flame ionization detector did, indeed, detect light hydrocarbons in the reactor effluent. Finally, Figure 5 presents independent evidence of the dual pathway for methanol decomposition. This figure present results for a set of experiments wherein: (i) methanol was fed to the reactor in a He carrier gas and, separately, (ii) methanol was fed to a fresh sample in a CO carrier gas. The catalyst used in each case was supported Rh-Mo, without any KNO<sub>3</sub> treatment. Prior to introducing the methanol feed, the catalyst had been reduced for 4 hr at 300 °C in excess H<sub>2</sub>. The selectivity measure of DME/other products displayed for both runs indicates that with the He carrier, DME is a small fraction of the ultimate decomposition products, while, in contrast, with CO as the carrier gas the DME is the dominant reaction product. In the case of the CO carrier gas, the CO is preferentially adsorbed on the active transition-metal sites of the catalyst, effectively poisoning their ability to decompose/react methanol to, say, CO, H<sub>2</sub>, CH<sub>4</sub>, C<sub>2</sub>H<sub>6</sub>, etc.

### Infrared Spectroscopic Studies

In order to obtain additional information about the nature and strength of the acid sites on the series of samples prepared during the last quarter, these samples were characterized by examining the characteristic infrared spectra in the range of 1400 to 1700 cm<sup>-1</sup> wavenumbers of adsorbed pyridine molecules. In this work, fine, powdered samples were pressed into thin wafers, placed in an air-tight IR transmission cell and subjected to the following treatment and analysis:

- 1) Samples were dehydrated to 300 °C under moderate vacuum, 10-2 Torr;
- 2) Samples were cooled to 200 °C and allowed to stabilize with regard to temperature fluctuations;
- Background spectra were set to the sample transmission at 200 °C prior to pyridine dosing;
- 4) Samples were dosed with gaseous pyridine at low pressure and allowed to equilibrate with the gas-phase pyridine;
- 5) Spectra were collected for sample equilibrated with pyridine;
- 6) Finally, sample were exposed to moderate vacuum (3 x 10<sup>-2</sup> Torr) and spectra were collected at 200, 250 and 300 °C for the pyridine-dosed samples.

The results of the IR analysis of the pyridine spectra suggest that (i) increasing the K loading on the native  $\gamma$ -Al<sub>2</sub>O<sub>3</sub> support reduces the Lewis acidity of the surface and (ii) the sequentially adsorbed transition metals in our system (Rh an Mo) ultimately titrated the residual acidity of the alumina.

The first of these conclusions is drawn from a combination of two sets of spectra, Figures 6 and 7. In Figure 6, pyridine has been adsorbed on the native alumina surface. Here, before exposing the doped surface to moderate vacuum, the spectrum contains signature peaks for both hydrogen bonded pyridine and pyridine coordinatively bonded to Lewis acid sites (hydrogen bonded pyridine at 1580 to 1600 cm<sup>-1</sup> and pyridine . coordinated with Lewis sites at 1453 cm<sup>-1</sup> and 1600 to 1633 cm<sup>-1</sup>). Characteristic peaks for pyridine chemisorbed at Brønsted acid sites are notably absent, as expected for predominantly Lewis acidic y-Al<sub>2</sub>O<sub>3</sub>. After exposing the alumina surface to moderate vacuum, the spectrum shows a marked reduction in hydrogen bonded pyridine, but the peaks for the residual Lewis acidity remain pronounced as is seen in the darker line of the figure. In contrast to spectra for bare alumina, those for K-doped alumina, as represented by the characteristic spectra in Figure 7, show an almost complete flattening of the Lewis acid signature peaks upon exposure to moderate vacuum (3 x  $10^{-2}$  Torr). Given that the sample associated with Figure 7 has an 11.9% K content (mass %), the spectra in Figure 7 indicate that the presence of the K has decreased the strength of the Lewis acid sites and may have reduced the total Lewis acid amount.

Perhaps the most important conclusions that can be drawn from the pyridine adsorption studies are born out by comparing the spectra for the following series of samples: (i) native  $\gamma$ -Al<sub>2</sub>O<sub>3</sub>, (ii) Mo on  $\gamma$ -Al<sub>2</sub>O<sub>3</sub>, and (iii) Rh-Mo on  $\gamma$ -Al<sub>2</sub>O<sub>3</sub>. This series mirrors the sequence of transition-metal chemisorption occurring during the synthesis of our metal-loaded, bimetallic catalyst. The spectra for the native Y-Al2O3, which appear in Figure 6, have already been discussed (vide supra). Figure 8 displays the spectra for Mo on y-Al<sub>2</sub>O<sub>3</sub>. Here, upon exposing the sample to moderate vacuum, the Lewis acidity remains evident. This suggests that either the process of chemisorbing the Mo does not effect the surface acid sites, or more realistically, the titration of Lewis acid sites by adsorbing Mo carbonyls from our Mo(CO)6 precursor is offset by the formation of Lewis acid sites at the MoOx layer ultimately formed on the surface after mild oxidation in air. Upon chemisorbing Rh, followed again by mild oxidation in air, Lewis acidity is once again quashed, as demonstrated by the spectra in Figure 9 for pyridine adsorption on a 2.8% Rh-3.4% Mo sample. Given that the residual acidity of the Rh-Mo/y-Al<sub>2</sub>O<sub>3</sub> sample is minimal, the process of K ion exchange would be expected to have little effect on the surface. In fact, these expectations are born out in Figure 10 for an ion-exchanged

5

л Г Rh-Mo/ $\gamma$ -Al<sub>2</sub>O<sub>3</sub> sample. In this sample, only a limited quantity of K remained on the surface after prolonged ion-exchange treatment, and the spectra are insignificantly different from those seen in Figure 9 for the bimetallic sample before ion exchange treatment.

### Summary


.

ł


The results of the pyridine adsorption studies on native and K-doped alumina provide fundamental grounding for the observed methanol dehydration activity of these samples. Both the reactor studies and the pyridine adsorption studies support the conclusion that the K-doped sample had reduced Lewis acidity. Moreover, we have demonstrated that we were able to measurably alter the acidity of the support surface by our ion exchange treatment. More significantly, when reactor results for transition-metal loaded samples are reconsidered in combination with their surface characteristics suggested by our pyridine adsorption studies, our hypothesis that Rh and Mo have ultimately titrated the support surface seems all the more convincing. Hence, in light of the pyridine adsorption results, the attenuation of a transition-metal based decomposition pathway for methanol on the metal-loaded samples—as seen in the reactor testing—is all the more reasonable.

. 6

**`**...



۲.



Conversion %




Figure 3

% Conversion




Figure 4

0.10

0.08

0.06

0:04


0.02

0.00

0.00

Weight % of Potassium in Sample

% Yield of DME



CARRIER эH asuodsay **DME/Other Products,** FID

Figure 5

**Pyridine Adsorption Spectra:** 

# Native Gamma-Alumina






Figure 6

**Pyridine Adsorption Spectra:** 

# K Doped Gamma-Alumina, 11.9% by Weight



evitelea



Relative Absorbance (Background: Sample at 200 C)




Figure 9

Wavenumber (cm-1)


•

÷.,

Pyridine Adsorption Spectra:

ы

K Doped Rh-Mo/Gamma-Alumina, <0.03% by Welght



Relative Absorbance (Background: Sample at 200 C)

# SATISFACTION GUARANTEED

NTIS strives to provide quality products, reliable service, and fast delivery. Please contact us for a replacement within 30 days if the item you receive filling your order. is defective or if we have made an error in

# E-mail: info@ntis.gov Phone: 1-888-584-8332 or (703)605-6050

# Reproduced by NTIS

National Technical Information Service Springfield, VA 22161

# This report was printed specifically for your order from nearly 3 million titles available in our collection.

For economy and efficiency, NTIS does not maintain stock of its vast collection of technical reports. Rather, most documents are custom reproduced for each order. Documents that are not in electronic format are reproduced from master archival copies and are the best possible reproductions available.

Occasionally, older master materials may reproduce portions of documents that are not fully legible. If you have questions concerning this document or any order you have placed with NTIS, please call our Customer Service Department at (703) 605-6050.

### About NTIS

NTIS collects scientific, technical, engineering, and related business information – then organizes, maintains, and disseminates that information in a variety of formats – including electronic download, online access, CD-ROM, magnetic tape, diskette, multimedia, microfiche and paper.

The NTIS collection of nearly 3 million titles includes reports describing research conducted or sponsored by federal agencies and their contractors; statistical and business information; U.S. military publications; multimedia training products; computer software and electronic databases developed by federal agencies; and technical reports prepared by research organizations worldwide.

For more information about NTIS, visit our Web site at <u>http://www.ntis.gov</u>.



**Ensuring Permanent, Easy Access to U.S. Government Information Assets** 



U.S. DEPARTMENT OF COMMERCE Technology Administration National Technical Information Service Springfield, VA 22161 (703) 605-6000

.